

parkmate®

PM-74AHD / PM-74AHDMPK

7.0" Multi-Channel AHD Monitor with 4 Camera Input & Display



USER MANUAL

YOUR SAFETY COMES FIRST™



CONTENTS

1.0	INTRODUCTION	2
1.1	Component List	2
1.2	Technical Specifications	4
1.3	Technical Specifications For PM-91AHR CAMERA (COMES BUNDLED WITH PM-74AHDMPK ONLY).....	4
2.0	PRODUCT OVERVIEW	5
3.0	GETTING STARTED	6
4.0	MENU NAVIGATION	7
4.1	Split Screen Options	7
4.2	Individual Camera Settings	7
4.3	Mirror Flip	8
4.4	Trigger Delay	8
4.5	Screen Rotate	9
4.6	Guidelines	9
5.0	WARRANTY TERMS & CONDITIONS	10
6.0	NOTES	13

INTRODUCTION

Thank you for purchasing Parkmate's PM-74AHD/PM-74AHDMPK multi-channel monitor. We know our product's safety features will enhance your driving experience.

DISCLAIMER

The PM-74AHD/PM-74AHDMPK has been designed to help drivers reverse and park, but is not a substitute for driver discretion. You should drive your vehicle with your full attention and use this system as an aid only. The manufacturer and its distributors do not guarantee or assume liability for collisions or damages while the PM-74AHD/PM-74AHDMPK is in use.

CAUTION

Ensure you are familiar with your local road legislation and you are using your camera within your countries' road laws.

COMPONENT LIST



7.0" IPS
AHD Monitor



Remote
Control



U Bracket



4 x U Bracket
Mount Bolts



Detachable
Sun Visor



User
Manual



AHD 1080P
Camera with 10m
cable (Only for
PM-74AHDMPK)



3M Heavy Duty
Dashboard Mount



Wire
Harness

IMPORTANT NOTICE

Please read this manual carefully before using the product.

Always insulate your wire connection points.

Always install wiring away from heat sources and electrical components.

Once installed, test your camera to ensure it is working correctly.

This system is an aid only. Drivers must always be careful when operating a vehicle, even while this system is in use.

Specifications are subject to change without notice.

WARNING

Do not disassemble the monitor or cut the monitor cable as this voids the warranty.

TECHNICAL SPECIFICATIONS



LCD Size:	7" Analogue High Definition (AHD) IPS Screen
Brightness:	600 cd/m2
Backlight:	LED
Screen Resolution:	600 H x 1024 W = 614400 Pixels
Video System:	PAL/NTSC auto
Camera Compatibility:	AHD (720P, 960P, 1080P) / CVBS compatible
Viewing Angle:	Left/Right/Up/Down: 90°
Quad Split:	In-built quad interface
View Mode:	Selectable Single /Dual/ quad-view
Trigger Priority:	CH 1 > CH 2 > CH 3 > CH4
Trigger Specification:	12-32V DC (adjustable delay time 0-20 seconds)
Input Voltage:	12-32V DC
Input Current:	700mA at 12V DC
Working Temperature:	-10°C to 65°C
Menu Language:	English
Audio:	N/A
Mirror Image:	Mirror image and rotation available
Camera Inputs:	4
Sun Visor:	Detachable

TECHNICAL SPECIFICATIONS FOR PM-91AHR CAMERA (COMES BUNDLED WITH PM-74AHDMPK ONLY)


Signal System:	NTSC
Horizontal Resolution:	1080 AHD
Minimum Illumination:	0.0 Lux
Diagonal Angle:	150°
Waterproof Rating:	IP69K
Nominal Voltage:	12V/24V
Working Temperature:	-30°C to 85°C
Cable Length:	10m
Night Vision:	Infrared LED's

PRODUCT OVERVIEW

Monitor



Remote Control



MONITOR

1. MENU: Press to enter menu settings
2. CH1▲: Function 1 - Switch to CAM1 in full aspect
Function 2 - Menu UP/DOWN selection
3. CH2▼: Function 1 - Switch to CAM2 in full aspect
Function 2 - Menu UP/DOWN selection
4. ⏻: Standby ON/OFF
5. CH3◀: Function 1 - Switch to CAM3 in full aspect
Function 2 - Menu LEFT/RIGHT selection
6. CH4▶: Function 1 - Switch to CAM4 in full aspect
Function 2 - Menu LEFT/RIGHT selection
7. MODE: Display Switch Mode

REMOTE CONTROL

1. MODE: Display Switch Mode
2. ⏻: Standby ON/OFF
3. MENU/LEFT/RIGHT/UP/DOWN
CHANNEL 1, CHANNEL 2, CHANNEL 3, CHANNEL 4
- 4.

GETTING STARTED

1. Attach the optional sun visor to the monitor (as shown in image 1).
2. Mount the monitor with the U bracket and screws or by using the heavy duty bracket with 3M tape.
3. Connect the RED wire (labelled ACC) to your chosen power source (either accessories or ignition). Both sources will be powered by a 12 or 24V battery, depending on the type of the vehicle. Refer to diagram on page 5.

Connect the YELLOW wire (labelled B+) to a constant 12 or 24V power source. This connection can be made directly from the positive battery terminal or to the vehicle's main fuse box.

Connect the BLACK wire to the chassis, while the vehicle is on solid ground (earth). This wire can be connected to the negative terminal of the vehicle's battery.

4. Connect 6-pin camera cables to the monitor.
To have a particular camera appear on the monitor when triggered, a (+) positive power feed is required. E.g.: The monitor's brown trigger wire must be connected to the (+) positive reverse lamp wire. This will ensure the reverse camera will appear on the monitor when your vehicle is in reverse. This wire only has power when the reverse gear is in use.

NOTE: The PM-74AHD/PM-74AHDMPK will only connect to cameras with a 6 Pin Mini Din connection.

Please confirm your chosen camera is suitable for your vehicle with your retailer.

Other cameras may require a 6 Pin Mini Din adapter.

5. When your vehicle is on, (either with the ignition turned on, or in accessory mode) your monitor will turn on automatically.
6. The default display is CH1 Full Screen. By pressing the Mode button continuously, the display input can be changed with the following sequence:

Sequence 1: CH 1 Full screen

Sequence 2: CH 2 Full Screen

Sequence 3: CH 3 Full Screen

Sequence 4: CH 4 Full Screen

Split Screen Options:

Sequence 5: All channels displayed

Sequence 6: CH 1 Half Screen with CH 2 and CH 3

Sequence 7: CH1 and CH 2 Half Screen

Sequence 8: CH 3 and CH 4 Half Screen

NOTE: The Mode Switch will skip a channel if there is no camera connected to that channel input.

When triggered, the mode will switch to full display.




Image 1


MENU NAVIGATION




The Parkmate logo will appear when you turn on the monitor for the first time. When the camera is connected, it will switch to Full Screen mode.

Select the display mode by pressing the Mode button. If the monitor is turned off, the most recent display mode chosen will be shown.


SPLIT SCREEN OPTIONS




Sequence 5



Sequence 6



Sequence 7



Sequence 8

INDIVIDUAL CAMERA SETTINGS

You can adjust the display settings of PM-74AHD's connected cameras.

Step 1: Press Menu

Step 2: Press UP/DOWN key to select the  icon

Step 3: Press RIGHT key to enter

Step 4: Press the DOWN key to select Camera Setting

Step 5: Press the RIGHT key to enter

Brightness: Increase or decrease brightness (Value 0-100, Default 50)

Colour: Increase or decrease colour saturation (Value 0-100, Default 50)


Contrast: Increase or decrease contrast (Value 0-100, Default 50)

Reset: Activating Reset will revert all the settings to Default 50


Step 6: Select the channel using the LEFT/RIGHT key

Step 7: Select the setting by pressing UP/DOWN key

Step 8: Change the selected setting by LEFT/RIGHT key



Step 4



Step 6

MIRROR FLIP

The Mirror Flip function will flip the image horizontally. It is best used when the camera is located on the front or side of a vehicle. When using the Mirror Flip function, it is not safe to use it while you're in reverse.

Step 1: Press MENU

Step 2: Press UP/DOWN key to select the  icon

Step 3: Press RIGHT key to enter

Step 4: Use UP/DOWN key to select the setting you require to change

Step 5: Use UP/DOWN key select Mirror Flip

Step 6: Press RIGHT key to enter camera selection

Step 7: Press UP/DOWN key to select the camera

Step 8: Press RIGHT/LEFT key to turn ON/OFF Mirror Flip

TRIGGER DELAY

When the trigger is activated on the respective camera, it will override any previous selections. The selected camera view will return to a full-screen image.

The default transition time between triggered screens is less than a second, until it is adjusted otherwise (this can be between 1- 20 seconds). When the trigger is deactivated, the display will revert to the selected mode display.

Increasing the trigger delay time will also increase the full-screen display time of this camera, even if deactivated.

Step 1: Press MENU

Step 2: Press UP/DOWN key to select the  Icon



Step 3: Press RIGHT key to enter

Step 4: Using UP/DOWN key select Trigger Delay


Step 5: Press RIGHT key to enter

Step 6: Press UP/DOWN key to select the camera

Step 7: Press LEFT/RIGHT key to change the trigger delay time (range is from 0-20 seconds)



Mirror/Normal Image Flip




Trigger Delay (Duration of the triggered camera display after trigger is off): 0-20 secs

SCREEN ROTATE

Screen Rotate will flip and rotate the orientation of the screen (i.e.: upside down / left and right).

To Rotate the screen follow the below steps:

- Step 1:** Press MENU
- Step 2:** Press UP/DOWN key to select the  Icon
- Step 3:** Press RIGHT key to select
- Step 4:** Use UP/DOWN key to select Rotate

There are 3 different ways to rotate the image:

- 1. Press Right Key Once:** Normal image switches to Mirror image
- 2. Press Right Key a Second Time:** Normal image rotated 180 degrees
- 3. Press Right Key a Third Time:** Mirrored image is rotated 180 degrees
- 4. Press Right Key a Fourth Time:** To revert to normal image orientation

EXAMPLE SCREENS (BELOW)



Image 1



Image 1 Mirrored



Image 1 Rotated
180 Degrees




Image 1 Flipped and
Mirrored

GUIDELINES

Enabling the Guidelines feature will show the guidelines when the camera is triggered and is ideal for reverse cameras. Guidelines are disabled by default. To turn guidelines on or off, please follow the below steps:

- Step 1:** Press MENU
- Step 2:** Press UP/DOWN key to select
- Step 3:** Press RIGHT key to enter
- Step 4:** Using UP/DOWN key select Guideline



The Guidelines function will turn on when the trigger has been activated.

- Step 5:** Press RIGHT key to enter
- Step 6:** Press UP/DOWN keys to select camera
- Step 7:** Press RIGHT and LEFT to turn ON/OFF Guidelines

WARRANTY TERMS & CONDITIONS

Our goods come with guarantees that cannot be excluded under the Australian & New Zealand Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This warranty is provided in addition to your rights under the Australian & New Zealand Consumer Law.

Directed Electronics Australia Pty Ltd (Directed Electronics) warrants that this product is free from defects in material and workmanship for a period of 12 months from the date of purchase or for the period stated on the packaging. This warranty is only valid where you have used the product in accordance with any recommendations or instructions provided by Directed Electronics.

This warranty excludes defects resulting from alterations of the product, accident, misuse, abuse or neglect.

In order to claim the warranty, you must return the product to the retailer from which it was purchased or if that retailer is part of a National network, a store within that chain, along with satisfactory proof of purchase. The retailer will then return the goods to Directed Electronics. Directed Electronics will repair, replace or refurbish the product at its discretion. The retailer will contact you when the product is ready for collection. All costs involved in claiming this warranty, including the cost of the retailer sending the product to Directed Electronics, will be borne by you.

Directed Electronics Address:

115-119 Link Road Melbourne Airport, 3045 Victoria. Australia

Ph: +61 03 8331 4800

Email: service@parkmate.com.au

To view the complete Parkmate range or for details on how to contact us, please visit our website at www.parkmate.com.au | www.parkmatehd.co.nz

INDEMNITY

You agree to defend, indemnify and hold harmless Parkmate and its subsidiaries and affiliates from and against any and all claims, proceedings, injuries, liabilities, losses, costs and expenses (including reasonable legal fees), including but not limited to, claims alleging negligence, invasion of privacy, copyright infringement and/or trademark infringement against Parkmate and its subsidiaries and affiliates or the Parkmate services, relating to or arising out of your breach of any provision of these terms, your misuse of the Parkmate or Parkmate services, or your unauthorized modification or alteration of products or software.

WARRANTY AND WARRANTY DISCLAIMER

Parkmate has a limited warranty whereby Parkmate warrants to and only to you that the Parkmate mirrors & monitors, sensors, cameras & accessories will be free from defects in materials and workmanship for one (1) year from the date of your purchase of the Parkmate mirrors & monitors, sensors, cameras & accessories (unless a longer warranty period is required by law). The specifics of this Parkmate limited warranty are at <https://www.parkmate.com.au/warranty>

To the extent possible under governing law, other than the above product warranty for the Parkmate mirrors & monitors, sensors, cameras & accessories you understand and agree that the Parkmate services are provided on an "as is" and "as available" basis. Parkmate makes no warranty that the Parkmate services will meet your requirements or that use of the Parkmate services will be uninterrupted, timely, secure or error-free nor does Parkmate make any warranty as to the accuracy or reliability of any information obtained through the Parkmate services (including third party content), that any defects in the Parkmate services will be corrected or that the Parkmate products or Parkmate services will be compatible with any other specific hardware or service.

You agree that Parkmate is not an insurer and that Parkmate is not providing you with insurance of any type. Any amounts that you pay Parkmate for the Parkmate service are not insurance premiums and are not related to the value of your vehicle or property, anyone else's property located in your vehicle or premises, or any risk of loss in your vehicle or at your premises. If you want insurance to protect against any risk of loss at your vehicle or premises, you will purchase it. In the event of any loss, damage or injury, you will not look to Parkmate to compensate you or anyone else. You release and waive for yourself and your insurer all subrogation and other rights to recover against Parkmate arising as a result of the payment of any claim for loss, damage or injury.

Parkmate's equipment and services do not cause and cannot eliminate occurrences of certain events, including, but not limited to, vehicle accidents, property damage, lost property, theft of vehicle, theft of property. Parkmate makes no guarantee or warranty, including any implied warranty of merchantability or fitness for a particular purpose, that the Parkmate equipment and services provided will detect or avert such incidents or their consequences. Parkmate does not undertake any risk that you or your vehicle or property, or the person or property of others, may be subject to injury or loss if such an event occurs. The allocation of such risk remains with you, not Parkmate.

Other than the above product warranty for the Parkmate mirrors & monitors, sensors, cameras & accessories Parkmate and its suppliers disclaim all warranties of any kind, whether express, implied, or statutory, regarding the Parkmate equipment and any associated app/service. Including any implied warranty of title, merchantability, fitness for a particular purpose, or non infringement of third party rights. Because some jurisdictions do not permit the exclusion of implied warranties, the last sentence of this section may not apply to you.

Parkmate hereby further expressly disclaims all liability for any claims for service failures that are due to normal product wear, product misuse, abuse, product modification, improper product selection or your non-compliance with any and all applicable federal, state or local laws. This warranty and warranty disclaimer give you specific legal rights, and you may have other rights that vary by state, province, or country. Other than as permitted by law, Parkmate does not exclude, limit or suspend other rights you have, including those that may arise from the nonconformity of a sales contract. For a full understanding of your rights you should consult the laws of your state, province, or country. For our Australian customers: please note that this warranty is in addition to any statutory rights in Australia in relation to your goods which, pursuant to the Australian consumer law, cannot be excluded.

LIMITATIONS OF PARKMATE LIABILITY

Under no circumstances will Parkmate be liable in any way for any content, including, but not limited to, the loss of content, any errors or omissions in any content, or any loss or damage of any kind incurred in connection with use of or exposure to any content posted, emailed, accessed, transmitted, or otherwise made available via the Parkmate app.

Parkmate liability for damages, especially for breach of duty or obligation, delay in performance, non-performance, or malperformance shall be precluded, except when these are due to negligent breaches of any significant contractual duty or obligation on the part of Parkmate. Any liability for negligence is limited to direct losses usually and typically foreseeable in such case. Should the claim for damages be based on willful or grossly negligent breach of contractual duty or obligation on the part of Parkmate, the preclusion and limitation of liability mentioned in the preceding sentences will not apply. The preceding preclusion and limitation of liability will also not apply to claims for damages arising out of loss of life, bodily injury or health impacts for which Parkmate may be liable, or for non-contractual liability.

Some states and countries do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Additionally, this provision is not intended to limit Parkmate's liability in the event of Parkmate's willful or intentional misconduct.





parkmate®

YOUR SAFETY COMES FIRST™



All Images, Information and Content are Copyright © 2021
Directed Electronics Australia Pty Ltd. All Rights Reserved.
www.parkmate.com.au | www.parkmatehd.co.nz

DIRECTED
AUSTRALIA & NZ

www.directed.com.au
www.directed.co.nz